

# UPPERFLOK

 FLOCK	 .3mm Fibers	 60° Blade	 MEDIUM pressure	 320°F	 15-20s	 PEEL: COLD
--	--	---	---	---	---	---

**CARRIER: Adhesive & Transparent Polyester**

## APPLIES ON

-  Cotton
-  Polyester
-  Acrylic & Similar Fabrics

## CARE

- Always respect the garment's instructions
- Allow 24 hours after application before washing
- Iron the backside only

## WASH

- Max 194°F
- Preferably inside out
- Do NOT bleach
- Tumble-dry
- Okay to Dry-clean

## STORE

- Up to 1 year
- In a dry room (60-85°F)
- Away from sunlight
- In vertical position

## APPLICATION

1. Cut the material in reverse with the recommended blade
2. Weed the excess material
3. Heat press on the garment at 320°F & Protect the polyester carrier with silicone paper 15 - 20 sec - medium pressure
4. Peel the carrier off when cold



NOTE: For best results, we recommend performing a TEST prior to starting standard production